

Selecting The Correct Moca for your Motorhome



1. Measure from the top of the chassis to the floor when fully laden.
2. With this dimension, confirm the part number for the appropriate kit from table below.

Please note, you may need to drill fitment holes if not already present.

Chassis type	Distance from top of chassis to floor when laden	Part No.
All types of chassis	290-490mm	1629224
All types of chassis	330-530mm	1629225
Euro-Chassis	280/290 (Front)	1629390
Euro-Chassis 230 / 244 / X250 (Front)	-	1629391
Ford flat floor chassis from 2003 (Front)	-	1629392
Other rear axle fitment options available on request		

AL-KO Kober Ltd, South Warwickshire Business Park, Kineton Road, Southam, Warwickshire, CV47 0AL

E-Mail: mail@AL-KO.co.uk www.AL-KO.co.uk

Due to a policy of continuous product improvement, AL-KO reserves the right to change technical specifications. Rev Date: 07/14. Issue 01.